



CHINA REFINE INDUSTRY CO.,LTD

Address of Xiamen Office: Room No.1505, Be-Top Plaza, No.617 Sishui Road, Wuyuan Bay, Huli District, Xiamen City, China.

Tel: +0086-592-5172805 / 5172802 / 5129830

Fax: +0086-592-5109830

E-mail: info@stone-union.com

Website: <http://www.stone-union.com> or <http://www.RefineStone.com>

How to Size Slabs?



Marble slabs are sold by the square inch.

- *Granite, concrete and marble slabs are used for a variety of home renovation project, such as marble floors, granite countertops or concrete flooring. Calculating slab size allows users to estimate the cost of a materials. Since granite and marble are sold per square inch, users can calculate the measure of a slab for a wall or countertop to determine the estimated pricing.*

Things You'll Need

- Measuring tape

Instructions

Place the slab on a flat surface. Remove any dirt, dust or materials surrounding the slab to get an accurate measurement.

Stretch the measuring tape along the edge of the slab to measure the length.

Search Videos & Articles to Find How to Do it Yourself - Free!



CHINA REFINE INDUSTRY CO.,LTD

Address of Xiamen Office: Room No.1505, Be-Top Plaza, No.617 Sishui Road, Wuyuan Bay, Huli District, Xiamen City, China.

Tel: +0086-592-5172805 / 5172802 / 5129830

Fax: +0086-592-5109830

E-mail: info@stone-union.com

Website: <http://www.stone-union.com> or <http://www.RefineStone.com>

Stretch the measuring tape across the slab to record its width.

Multiply the length by the width. You may use a calculator if necessary. The resulting number is the size of the slab in square inches.